






# LUMINARA®


BRINGING MORE MAGIC TO EVERY MOMENT™

## 10 BUTTON REMOTE



### OPERATION

- Your Luminara candle must be turned “ON” for the remote to function. Your remote will not function if your Luminara candle is in the “TIMER” mode. To use remote, point towards candle and press  to turn on/off.
- To use TIMER, The candle has four separate timer modes to choose from: 4hr, 6hr, 8hr or 10 hr. To activate the desired timer setting while candle is ON: press button of your desired timer setting     and hold for approximately one second. The LED will blink once a timer setting is chosen. Once complete, candle will automatically turn on at the set time every day and turn off after the selected number of hours.



### • FLICKER & STATICS

To choose flicker or static light mode: while candle is ON, press  button on the remote. Flicker is the default setting for the Moving Flame (flame sways side to side). Static mode is continuous light with no flame movement.

### • FAST OR SLOW

To choose flame movement speed: While candle is ON, press either fast  or slow  button. Fast is the default setting.

### • DIMMER CONTROL

The pillar has five brightness settings to  choose from (the default setting is level 4). To dim your candle in either flicker or static mode, point remote at the pillar and press button to dim candle one level. To adjust pillar to a brighter setting, use the  button. Higher brightness levels consume more battery life.



### BATTERY INSTALLATION & MAINTENANCE

- Your Luminara remote control requires (2) two Lithium CR2025 battery (included)
- When you receive your remote and prepare for first time use, you must pull the plastic tab out from the battery compartment at the bottom of the remote.

### REMOTE NOT WORKING?

- Pull out the plastic tab from the battery compartment before use.
- Make sure that the power switch on your candle is in the ON position.
- Candle color and finishes may impact the range of the remote.
- Make sure that your candle is remote-compatible.
- Your battery may be dead. Replace the battery.

### WARNING:

The batteries included with this product are non-rechargeable, disposable lithium batteries **NEVER** attempt to recharge a disposable lithium battery.

Disposable lithium batteries can EXPLODE, CATCH FIRE, and/or CAUSE BURNS if disassembled, punctured, cut, crushed, short-circuited, incinerated, recharged, or exposed to water, fire, or high temperatures.

Batteries that come into contact with each other or with metal objects may SHORT-CIRCUIT, HEAT UP and/or CATCH FIRE.

**DO NOT** remove replacement batteries from their plastic casing until ready for use in the product.

**DO NOT** place loose batteries in a pocket, purse, drawer, or other receptacle containing metal objects.

**DO NOT** stack batteries on top of each other.

**DO NOT** store batteries with hazardous or combustible material; store in a cool, dry, ventilated area.



### BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN

Swallowing may lead to serious injury or death in as little as 2 hours due to chemical burns and potential perforation of the esophagus. Immediately see doctor and call (800) 498-8666. Dispose of used batteries immediately. Risk of injury due to fire, explosion or leakage. Do not disassemble, charge, crush or expose to fire or high temperatures.

### CAUTION

Luminara candles can be made of real wax, plastic, or other material finishes and are flammable. Do not attempt to light any component of your Luminara product. Doing so may result in personal injury or damage to your candle and components and will void the warranty.

Your Luminara candle may be intended for indoor or outdoor.

**For Indoor candle made of real wax keep out of direct sunlight, away from heat sources, and out of extreme temperatures or your Luminara candle may fault. Doing so may result in damage to your candle, or its components, and will void the warranty.**

Place your candle on a protective base, on a candle stand, or in a lantern to protect furniture from possible debris. Luminara candles are breakable. Dropping can break or damage the candle or its internal components, voiding the warranty. This product contains small parts, which, if removed, can pose a choking hazard. Keep away from small children.

Insert batteries as displayed on the battery compartment. Failure to insert the batteries correctly may result in damage to your candle or personal injury and will void the warranty.

- Do not mix old and new batteries.
- Replace all batteries of a set at the same time.
- Do not mix Alkaline, Carbon-Zinc, NiMhd, or NiCad batteries.
- Please recycle used batteries or dispose of them as per state and local guidelines.
- Do not dispose of batteries in fire.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Clean the battery contacts and also those of the device prior to battery installations.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment if it is not to be used for an extended period of time.
- Remove used batteries promptly.

### FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

MODEL#ES010042-R1

CAN ICES-3(B)/NMB-3(B)

Manufactured and distributed by L&L Candle Co., LLC. Luminara® and other related trademarks are trademarks of L&L Candle Co, LLC, registered or used in many jurisdictions worldwide.  
© 2021 Patents: [www.Luminara.com/Patents](http://www.Luminara.com/Patents)

We hope that you will be delighted with the beauty and functionality of your Luminara® Candle. As with any traditional candle, care is required to maintain your Luminara® Candle so that you can enjoy it for years to come. For optimal performance, please take the time to read the instructions.